

Application of BMW Tint

- Prepare and complete your wheel to and including clearcoat stage, ensure the clear coat is fully cured.
- Mix BMW Tint 2parts Tint :1 Modified thinner.
- Ensure wheel is clean and free from dust.
- Apply two consecutive coats to the Diamond cut area approx. 1.5 to 2 bar with either a 0.8 or 1.0 fluid tip and leave to flash off.
- Repeat the process until the desired level of tint is required.
- It can be as many as 12 coats as different wheel manufacturers manufacturing for BMW have different levels.
- We therefore suggest if you are doing one wheel that you bring a wheel in the booth to gauge the depth of tint required before clear coating to finish.
- Please note this can also be applied to the Honda Diamond Cut Wheels.
- Please note this will need to cool down to 50°C before applying.